

If front step is needed to guide scraper around steels, ensure it is a minimum of 14" wide step for front feet.

It must be wide enough to step on or cows will stand off it and reduce feed intake.

DATE:

SCALE:

WILSON AGRICULTURE Dairy Housing Specialists www.wilsonagri.co.uk

DRAWN BY:

Ivor Davey

ivor@wilsonagri.co.uk

Scale: 1:35



[figures are for guidance only]