

AquaTip

The Easy Clean Trough



This unique design will empty all the grime and impurities from the bottom of the tank. Turn it upright again and it will re-fill with fresh, clean water.

- 2m long - 220 litres capacity (suitable for ≈ 50 cows*)
- 3m long - 376 litres capacity (suitable for ≈ 82 cows*)

Install your Aqua Dump 34 inches from the floor to the top of the trough



DIMENSIONS

Length:

Add 20cm to the length to allow total width of brackets etc.

eg: 2m Aqua-Dump is 2.15m to outside of mountings.

Width:

All Aqua-Dumps are approx. 64cm wide. Usually allow 75cm to enable room for pipes etc.

Depth:

All Aqua-Dumps are approx. 50cm.

Aqua-Dumps are not supplied with ball valves.



Aqua Dumps can be floor mounted on a plinth or additional mounting brackets.

Wilson Agriculture
Tel: 02870 868430 Fax: 02870 868803
e-mail: cowcomfort@wilsonagri.co.uk
www.wilsonagri.co.uk

* based on Defra recommendation of 1m²/60cows