

# WAVE NECK BAR




## Key Benefits:

- Allows natural lunging completely unrestricted.
- encourages the cow to accurately position herself in the stall before lying down.
- Encouraging accurate positioning ensures the cow experiences optimum comfort in the stall while helping to keep the bed clean.
- Manufactured to fit any stall width
- Increases the neck rail height
- 4 cow spaces per length
- Wave neck bar allows the cow to stand comfortably on her stall before lying. In comparison to standard neck rail this prevents the animals neck rubbing on the rail.
- Hot dip galvanised to ISO 1461


## Simple Installation:

The neckbar is installed along the top rail of the cow stalls using U-Bolts.

N.B. 1.2m centres shown. Can be bent to specific spacings.



PIPE DETAILS:  $\varnothing$  48.3mm PIPE X 2.6mm WALL



**Wilson  
Agri**

Call from outside the UK: 0044 28 7086 8430. 75 Drumcroone Road, Coleraine, BT51 4ED

